



# KUT INJECTOTHANE 100

## Polyurethane Based Flexible Low Viscosity Crack Injection System

GAP – 09 - 0104

### DESCRIPTION

**KUT INJECTOTHANE 100** is a two part solvent-free, low viscosity high tensile strength polyurethane based system designed to form a strong permanent bond and seal in cracks in dry, damp or wet concrete and masonry.

### USES

- ★ For injecting into cracks for, dry, damp or wet concrete or masonry. Especially as an underlay for poorly ventilated working areas.
- ★ May be used to form bowl-shaped sealing layers around construction, since it adheres well to sand and concrete (wet or dry).
- ★ **KUT INJECTOTHANE 100** is designed as a permanent solution to seal and bond cracks in concrete and masonry. Crack widths of between 0.2mm and 10 mm can be treated depending on requirements.

### ADVANTAGES

- ★ Does not attack bitumen, sealing materials and foils modified with Bitumen or **STYROPOR** and **PUR - Foam**.
- ★ Even underwater, **KUT INJECTOTHANE 100** provides very effective sealing, bonds with the above sealing materials and sealing foils.
- ★ Low viscosity allows penetration into fine cracks.
- ★ Good adhesion to dry/wet substrates.
- ★ High tensile strength, withstands high hydrostatic pressure.
- ★ Displaces water optimally.
- ★ Formulated to use in hot climates.
- ★ Flexible to withstand differential movement.

### TYPICAL PROPERTIES

1. **Solids contents (%)** : 100.
2. **Pot life @ 25° C** : 30 to 45 minutes.
3. **Minimum temperature for hardening** : 0° C.
4. **Hardness Shore A** : 60 ± 5
5. **Tensile Strength** : 2.5 N/mm<sup>2</sup>.
6. **Extensibility (%)** : 80.

### SURFACE PREPARATION

Clean the surface and remove any dust, unsound or contaminated material, paint, grease, corrosion deposits or algae. The surface should preferably be prepared using high pressure water jetting or light abrasive blasting, followed by thorough washing to remove dust and remaining particles. Dirt alone may be removed with wire brush cleaning, detergent scrubbing or the use of an appropriate degreaser. The effectiveness of decontamination can be accessed by a pull-off test. Blow the cracks and treated surface with oil free air to ensure complete removal of all dust and loose particles. Ensure that the surfaces are blown dry.

### FIXING INJECTION PACKERS

The Injection packers or injection nipples shall be inserted into pre drilled holes at intervals along the length of each crack. The distance between each packer will depend upon the width and depth of the crack. Spacing shall be close enough to ensure that the resin will penetrate along the crack to the next point of injection. The surface of the cracks between the packers shall be sealed with **KUT GEL EP**. Both sides of any cracks which go all the way through a wall or slab shall be sealed in this way. **KUT GEL EP** shall be allowed to cure for 8 hours at 35° C. At low ambient temperatures (5° C to 12° C) the curing time will be extended and the applicator shall ensure that the surface sealant has adequately cured prior to continuing. One of the injection hose shall be attached to the lowest packer on vertical cracks or to either end of the horizontal cracks.

### APPLICATION

Thoroughly mix the entire **Part A** and **Part B** contents for 3-5 minutes preferably by slow speed drill. For part mixes mix 1 vol. of **Part B** with 3 vol. of **Part A**.

1. **KUT INJECTOTHANE 100** can be used:

- (a) With standard injection equipments with closed containers (pressure pots) capable of working at pressures up to 1 N/mm<sup>2</sup> (1 bar).
- (b) With plastic or foil lined cartridges using a hand operated skeleton cartridge gun at low pressures.



Specialities Construction  
Chemicals Factory

Amghara Industrial Area, P.O.Box: 23595 Safat, 13096 Kuwait, Tel: +965 4565165 - 4565145 Fax: +965 4565135  
Email: technical@aspeckuwait.com



- Following completion of the injection works the injection system shall be allowed to cure for 24 hours and shall be left undisturbed for this time.
- FOR FINISHING** : Remove any packers or nipples and make good any holes or void with **KUT GEL EP** and allow to cure. **KUT GEL EP** can be ground off with an angle grinder or softened with a blow lamp and peeled off. Do not allow to burn.
- When injection foam is needed mix **Part C** with **Part A + Part B** in below given proportions. It is advisable to mix **Part C** with **Part A** prior to mixing with **Part B**.

#### MIXING RATIOS FOR KUT INJECTOTHANE 100 – PART C

	For Flexible Foam	For Rigid Foam
<b>PART A</b>	1 ltr.	1 ltr.
<b>PART B</b>	1 ltr.	2 ltr.
<b>PART C</b>	40 ml	50 ml
Approx. volume increase	4 times	7 times

Actual ratio will vary a little on actual site mixing.

#### LIMITATIONS

**KUT INJECTOTHANE 100** should not be used in the presence of running water.

#### PACKAGING

**KUT INJECTOTHANE 100** : 850 kg & 21 kg pack  
**KUT GEL EP** : 0.75 kg. Pack.  
**KUT SOLVENT PS** : 5 litre cans.

#### PRECAUTIONS

**CLEANING** : Spillages should be absorbed with sand or earth etc. and disposed in accordance with local regulations.

**STORAGE** : Store in dry conditions upto 10°C-25°C. **Part A** and **Part B** are sensitive to moisture. For this reason the contents of container once opened should be used immediately. Shelf life is 1 year for **Part A** and 6 months for **Part B** in tightly closed original container under dry conditions.

#### FIRE RESISTANCE

The product is non flammable but will burn in a fire. **KUT INJECTOTHANE 100** and **KUT GEL EP** should be removed from tools, equipment and mixers with **KUT SOLVENT PS** immediately after use. Hardened material can only be removed mechanically

#### HEALTH AND SAFETY

**KUT INJECTOTHANE 100** should not come in contact with skin and eyes or be swallowed. Avoid prolonged inhalation of the vapours. Some people are sensitive to isocyanates, therefore, protective gloves, goggles and barrier cream should be used. Ensure adequate ventilation and if working in enclosed areas, suitable breathing apparatus should be used. If mixed resin comes in contact with skin, it should be removed with a resin removing cream followed by washing with soap and water. Should accidental eye contamination occur with any of the above products, wash well with plenty of clean water and seek medical advice immediately. If swallowed, seek medical attention immediately. **DO NOT INDUCE VOMITING**. Refer our safety data sheets before using this material.

**ASPEC** endeavours to ensure that any information contained herein is true, accurate and represents our best knowledge and experience, no warranty is given or implied with any recommendations made by us, our representatives or distributors, as the conditions of use and the competence of any labour involved in the application are beyond our control.

**Distributor:**